



PWC-1500 Parts List

Item No.	Description	Part Number
P1	Main Tank Cover, round*	cl1 9210/EG
P2	Top Cover, square*	cl5 9600
P3	Upper Front Panel*	cl5 9601
P4	Lower Front Panel*	cl5 9602
P5	Faucet Cover	cl5 9603
P6	Base	cl5 9604
P7	Drip Tray Set	cl5 9605
P8	Handle	cl1 9235/EG
P9	Faucet, Cold Water	cl5 9606
P10	Faucet, Hot Water	cl5 9607
P11	Strain Relief	
P12		
P13	Nut, Faucet	cl5 9607
P14	Rubber Pad	cl1 9249
P15	1/4" tubing	
P16		
P17	Dust Cover	cl1 9201
P18	Fitting, elbow, 1/4 x 1/4	cl5 9608
E1	PC Board	cl1 9253
E2	Cold Temperature Switch	cl1 9237
E3	Power Switch	cl1 9238
E4	Fuse Housing	cl1 9252
E5	Fuse	cl1 9262
E6	Screw, 4 x 6	cl1 9256
E7	Compressor	cl1 9218
E8	Power Cord	
H1	Hot Tank	cl5 9617
H2	92°C Temperature Sensor	cl1 9277
H3	82°C Temperature Sensor	cl1 9251
H4	Screw 5 x 22	cl1 9257
H5		
H6		
H7	Screw, Hot Tank	cl1 9245
H8	Silicon Tube Elbow, 175 x 4	cl1 9230
H9	Silicon Tube Elbow, 160 x 4	cl1 9227
H10	Silicon Tube St, 5 x 250	cl5 9618
H11	Silcon Vent "T" Tube	cl1 9225
H12		
H13		
H14	Silicon Tube Elbow 50x60x4	cl1 9028
H15	Drain Fitting Nut	cl1 9240
H16	Tank Drain Connector	cl1 9246
H17	Drain Plug	cl1 9248
H18	Silicon Plug	cl5 9619

Item No.	Description	Part Number
M1	Upper Plate	cl5 9609
M2	Mounting Plate	cl1 9217
M3	Left Side Panel	cl5 9610
M4	Right Side Panel	cl5 9611
M5	Rear cover	cl1 9236
M6		
M7	Screw	
M8	Screw	
M9	Condensor	cl5 9612
M10	Dryer	cl1 9241
M11	Capillary Tube	
M12		
M13	Spring Clip	cl1 9215
M14		
M15	Screw, 5 x 22	cl1 9257
M16	Screw, 4 x 25	cl1 9255
M17	Screw	cl5 9613
M18	Screw, 3 x 8	cl5 9614
M19	Screw, 4 x 12	cl5 9615
M20	Pivot Pin	cl5 9616
O1	Indicating Panel, (sticker)	cl5 9622
O2		
O3	Mechanical Float Valve	cl1 9233
C1	Cold Water Tank	cl1 9223
C2		
C3	Silicon Gasket	cl1 9224
C4	Cold Tank Outlet Connector	cl1 9242
C5		
C6	Nut, Faucet	cl5 9620
C7	Insulating Foam, Cold Tank	cl1 9222
C8	Bottom Insulating Foam	cl5 9621
C9		
C10	Silicon Tube Elbow, 75 x 4	cl1 9244
C11	Insulating Sleeve	cl1 9214